
Safety equipment

Sacrificial anodes

For increased hygiene: Anode individually packed in poly bag



Application Protection against frequently unnoticed corrosion damage in water heaters. Primarily for use in enamelled boilers or hot water tanks with other types of passive protective coatings. Defective areas in enamel or other passive protective coatings are subject to corrosion; this causes a flow of current which is transformed into a protective current by the anode material. The anode material thus falls victim to electro-chemical corrosion. Since the protective function of the anode rod is not unlimited, consumed anodes have to be replaced.

Anode I

Description Sacrificial anode Ø 22, 26, 33 mm as per EN 12828, made of magnesium alloy, for isolated installation. With M8 male, threaded connection, isolating piece and earth cable. Consumption check with AT1 anode tester.

Sacrificial anode

Sacrificial anode Ø 22, 26 or 33 mm as per EN 12828, made of magnesium alloy, suitable for all standard tanks. With screw fitting G³/₄, G1 or G1¹/₄, without signal. See the ordering table for various versions with different lengths, threads and diameters.

Chain anode

Flexible sacrificial anode Ø 22 mm as per EN 12828, made of magnesium alloy. A flexible anode is used if there is insufficient space to install a rigid anode. Consisting of five individual elements along a stainless steel rope and a G34 screw fitting or M8 male-threaded connection (see also Anode I) Length approx 800 - 900 mm.



Anode tester AT1

Tester for consumption check of anode I or isolated standard sacrificial anodes.

- Handheld tester with 4-level LED indication
- Fast and easy indication of the condition of the anode
- Reliability of the water heater due to preventive maintenance consumed anodes are replaced in good time

| DG: G | PG | | Ĩ.v. | Part no. | Price € |
|--------------------------------------|----|---|------|----------|---------|
| Anode I 22–500-M8 | 3 | 1 | 45 | 69806 | |
| Anode I 26–500-M8 | 3 | 1 | 35 | 69811 | |
| Anode I 33–500-M8 | 3 | 1 | 20 | 69808 | |
| Sacrificial anode 22–500-¾ | 3 | 1 | 40 | 69815 | |
| Sacrificial anode 22–700-34 | 3 | 1 | 30 | 69817 | |
| Sacrificial anode 26–500-1 | 3 | 1 | 30 | 69819 | |
| Sacrificial anode 26–700-1 | 3 | 1 | 20 | 69821 | |
| Sacrificial anode 33–550-1¼ | 3 | 1 | 15 | 69825 | |
| Chain anode 22–800-¾ (5 elements) | 3 | 1 | 35 | 69829 | |
| Chain anode I 22–900-M8 (5 elements) | 3 | 1 | 35 | 69804 | |
| Accessories (DG: H) | | | | | |
| Anode tester AT1 for anode I | 4 | 1 | - | 69842 | |

